



REBAR CUTTER - CARBIDE TIP

RELTON ROTARY ONLY MULTIPLE-CUTTER BITS

Non-Removable-Shank, Multiple Cutter Bits

Concrete-Termite® Solid Body Style



Diameter Point	Shank	Overall Length	Drilling Depth
3/16"	3/16"	4"	2 3/16"
1/4"	1/4"	5"	3"
5/16"	1/4"	5"	3"
3/8"	1/4"	5"	3"
3/8"	1/4"	8"	6"
7/16"	1/4"	5"	3"
1/2"	3/8"	8"	5"
1/2"	1/2"	18"	14 1/2"
9/16"	3/8"	8"	4 1/2"

Concrete-Termite® Core Style



Diameter Point	Shank	Overall Length	Drilling Depth
5/8"	1/2"	8"	4 1/2"
3/4"	1/2"	8"	4 1/2"

Removable-Shank Core Bits



Core Body - 4 1/2" OAL, 3 1/2" Core Depth

Diameter	Sugg. RPM	Shank Dia.	To Make Overall Bit Length
7/8"	350-750	1/2"	9"
1"	350-750		
1 1/8"	350-750		
1 1/4"	350-750		
1 3/8"	350-750	1/2"	12"
1 1/2"	350-750	1/2"	18"
1 5/8"	350-750	1/2"	24"
1 3/4"	350-750	1/2"	9"
2"	250-450		
2 1/4"	250-450		
2 1/2"	250-450		
3"	250-450	1/2"	24"

E-Z Starter Points for TD Core Bits

Use to help keep the core bit from "skipping" across the masonry when first contact is made. The E-Z in-and-out design is quick and simple to use.



Will Fit These Core Bit Diameters

5/8", 3/4", 7/8", 1", 1 1/8", 1 1/4",
1 3/8" thru 1 5/8",
1 3/4" thru 2 1/4",
2 1/2" thru 3"

Non-Removable-Shank Rebar Cutters



At last, the answer to drilling through concrete-embedded rebar! No more broken or shattered hammer bits; now you can drill through the rebar and not have to relocate the hole to avoid the rebar!

Diameter	Overall Length	Suggested RPMs
3/8"	8"	850-1200
1/2"	12"	850-1200
1/2"	18"	850-1200
9/16"	12"	850-1200
5/8"	12"	750-1000
5/8"	18"	750-1000
11/16"	12"	750-1000
3/4"	12"	600-850
3/4"	18"	600-850
3/4"	24"	600-850
13/16"	12"	600-850

Removable-Shank Rebar Cutters



Diameter	Overall Length	Suggested RPMs	Shank Dia.	To Make Overall Bit Length
7/8"	12"	600-850	1/2"	9"
1"		500-750		
1 1/8"		500-750		
1 1/4"		450-600		
1 3/8"	12"	450-600	1/2"	18"
1 1/2"		350-500		
1 3/4"		350-500		
2"		350-500		
2 1/2"	12"	350-500	1/2"	9", 12" 18", 24"
2 1/2"	12"	350-500		

Diamond Drill Rig Adapters

Adapt core bits, rebar cutters and hole saws for use on diamond drill rigs. May be used wet or dry cut.






Will Fit These Products	Thread Size
3/4" - 7/8" Hole saws - 1 3/4"	1/2 - 13 to 5/8 - 11
1" - 4" Hole Saws, 2" and up	3/4 - 10 to 5/8 - 11
1" - 4" Hole Saws, 2" and up	3/4 - 10 to 1 1/4 - 7

Easy As...

When rebar is encountered, immediately stop the hammer and remove the bit from the hole, failure to stop immediately will severely damage a carbide hammer bit.

Mount a rotary rebar cutter in a standard 1/2" drill motor or 1/2" hammer drill (with the selector in the rotary-only position); insert the rotary rebar cutter into the hole and drill through the embedded rebar.

Remove the rotary rebar cutter after the rebar has been drilled completely through and finish drilling the hole with the rotary hammer and bit.



Notice: The Relton carbide-tipped rotary rebar cutter is designed for use in standard 1/2" drill motor, but a hammer drill with a standard 3-jaw chuck may be used provided the selector mechanism on the hammer drill is kept in the rotary only position. The Relton carbide-tipped rotary rebar cutter is intended for rotary drilling only; percussion (hammering action) will damage the tool.